





E-Mail: [sales@incartec.co.uk](mailto:sales@incartec.co.uk)  
 Website: [www.incartec.co.uk](http://www.incartec.co.uk)

**Steering Control Adapter 29-703**  
 Landrover Freelander 2 with Alpine premium  
 ( Amplifier bypass cable needed)



**1-ALWAYS CONNECT THE HEAD-UNIT CABLE ADAPTER 1st before ignition is turned on!**



**THIS CAR HAS MOST FIBER OPTICS. THE AMPLIFIER WILL NEED TO BE BYPASSED TO GET AUDIO FROM A NEW HEAD-UNIT TO THE CARS SPEAKERS**


1. Choose a head-unit adapter from the list overleaf and connect it to the USC black box.
2. Turn off the ignition supply to the car!
3. Remove the OEM head-unit and identify the Green 10 way connector .
4. Connect the white and purple cable to the car connector
5. Check that the red wire is a 12V IGNITION source in the car then turn on ignition
6. Test unit before fully fitting radio and trims back.

**If Problems:** Check that correct adapter has been used and links are in the correct place. Always disconnect from the power supply if you change the head-unit adapter lead. Check that Red wire is 12V ignition and not Permanent power. Check that head-unit is earthed and black wire is earth. Check all connections are the same as the wiring diagram shown here




E-Mail: [sales@incartec.co.uk](mailto:sales@incartec.co.uk)  
 Website: [www.incartec.co.uk](http://www.incartec.co.uk)

**Steering Control Adapter 29-703**  
 Landrover Freelander 2 with Alpine premium  
 ( Amplifier bypass cable needed)



**1-ALWAYS CONNECT THE HEAD-UNIT CABLE ADAPTER 1st before ignition is turned on!**




**THIS CAR HAS MOST FIBER OPTICS. THE AMPLIFIER WILL NEED TO BE BYPASSED TO GET AUDIO FROM A NEW HEAD-UNIT TO THE CARS SPEAKERS**

1. Choose a head-unit adapter from the list overleaf and connect it to the USC black box.
2. Turn off the ignition supply to the car!
3. Remove the OEM head-unit and identify the Green 10 way connector .
4. Connect the white and purple cable to the car connector
5. Check that the red wire is a 12V IGNITION source in the car then turn on ignition
6. Test unit before fully fitting radio and trims back.


**If Problems:** Check that correct adapter has been used and links are in the correct place. Always disconnect from the power supply if you change the head-unit adapter lead. Check that Red wire is 12V ignition and not Permanent power. Check that head-unit is earthed and black wire is earth. Check all connections are the same as the wiring diagram shown here

CHOOSE THE CORRECT HEAD-UNIT ADAPTER FROM THOSE BELOW


29-001 Alpine




29-002 Blaupunkt




29-003 Clarion




29-004 JVC




29-005 Kenwood  
Single wire




29-005D Kenwood  
4 pin DIN Plug




29-006 Panasonic  
Standard CD units




29-006A Panasonic  
AV head-units




29-009 Siemens  
VDO




29-008 Sony  
3v & 5v units



29-011 Zenec




29-020 Pioneer &  
Sony




Special external drive  
PCB version

CHOOSE THE CORRECT HEAD-UNIT ADAPTER FROM THOSE BELOW


29-001 Alpine




29-002 Blaupunkt




29-003 Clarion




29-004 JVC




29-005 Kenwood  
Single wire




29-005D Kenwood  
4 pin DIN Plug




29-006 Panasonic  
Standard CD units




29-006A Panasonic  
AV head-units




29-009 Siemens  
VDO




29-008 Sony  
3v & 5v units



29-011 Zenec



29-020 Pioneer &  
Sony



Special external drive  
PCB version