



1 This is how the original dashboard looks like.



5 Unscrew and save the 6 screws circled in red.



2 Unscrew and save the 4 screws circled in Red and remove the plastic panel.



6 Unscrew and save the 2 screws circled in red. Remove the keys panel. Disconnect and remove the radio from the radio tunnel



3 Remove the OEM fascia plate as shown in the picture.



7 Fix the mounting brackets to the radio by tightening the 4 screws for side circled in red.



4 Remove the Air conditioning panel.



8 Connect all cables, verify the proper functioning of the system and install the radio in the radio tunnel by tightening the screws save previously.

9



9 Install the panels you have removed and install the facia plate supplied in the kit.

This is the final result.

ATTENTION!
This kit is NOT compatible with OEM touch display!

