



## **Installation Instructions**

- 1. Ensure your vehicle's ignition if off with the key removed.
- 2. Remove the original Head Unit (radio) with reference to the manufacturer's instructions.
- 3. Assemble the Patch Lead (SOLD SEPERATELY) so that it is compatible with the Head Unit being installed.
- 4. Connect the patch lead to the Steering Control Interface (Black box on 29-679 harness). THIS MUST BE DONE FIRST BEFORE ANY OTHER CONNECTIONS.
- 5. Connect the 29-679 from the car to the new radio.
- 6. With reference to the diagram and description above, connect the green wire from the 29-679 interface to the 2<sup>nd</sup> pin (Blue or Green wire) on the Original Bluetooth module. Disconnect the cars original Bluetooth module.
- 7. Test the system fully ensuring all controls function before refitting the new Head Unit.

## **Troubleshooting**

 Check that the correct patch lead has been used and links in the connector are in the correct place (Always disconnect from the power supply if you change the lead).