



Installation Instructions

1. Ensure the vehicle ignition is off with the key removed.
2. Remove the original Head Unit (radio) with reference to the manufacturer's instructions.
3. Assemble the Patch Lead (Sold Separately) with reference to the instructions supplied with the patch lead
4. Connect the patch lead to the new head unit and then to the Steering Control Interface (Black box on 29-677 harness).
THIS MUST BE DONE FIRST BEFORE ANY OTHER CONNECTIONS
5. Disconnect the male connector from the back of the original Head Unit and connect this to the female connector on the 29-677 harness.
6. Connect the ISO connectors of the 29-677 to the new head unit.
7. Locate the 8-way connector behind the Head Unit.
8. With reference to the diagram above, Connect the **Purple wire from the interface to the Blue wire on the 8 Way connector** and the **White wire from the interface to the Pink wire on the 8 way connector**
9. **FOR LATER SUBARU CARS WITH KENWOOD OEM NAVIGATION ONLY!**
The 24 pin connection behind the radio houses the steering wheel control lines. Conenct the purple wire from the interface to pin 3 (brown) and the white wire from the interface to pin 15 (yellow).
10. Test the system fully ensuring all controls function before refitting the new Head Unit.

Troubleshooting

Check that the correct patch lead has been used and links in the connector are in the correct place

Always disconnect from the power supply if you change the lead

