

# 29-669



## Suzuki steering wheel control interface

### Supported functions

- Volume up
- Volume down
- Seek/track up
- Seek/track down
- Source
- Mute
- Phone answer\*
- Phone reject\*
- Phone voice\*



### Connection instructions

**Connect the head unit specific patch lead to the interface first.** If using a universal patch lead, check it is setup correctly. Refer to the diagrams overleaf to check the patch lead is correct.

Connect the ISO connectors and patch lead to the new head unit.

Connect the 29-669 harness to the vehicle harness.

Test the steering controls.

Fit the head unit into place and test the steering controls again.

### Notes

\* Vehicles with phone buttons

# 29-669



## Suzuki steering wheel control interface

### Supported functions

- Volume up
- Volume down
- Seek/track up
- Seek/track down
- Source
- Mute
- Phone answer\*
- Phone reject\*
- Phone voice\*



### Connection instructions

**Connect the head unit specific patch lead to the interface first.** If using a universal patch lead, check it is setup correctly. Refer to the diagrams overleaf to check the patch lead is correct.

Connect the ISO connectors and patch lead to the new head unit.

Connect the 29-669 harness to the vehicle harness.


Test the steering controls.

Fit the head unit into place and test the steering controls again.


### Notes

\* Vehicles with phone buttons


## Patch lead wiring configurations




**29-000 Self learning units**  
Single wires pins 1 and 2  
No loops




**29-001 Alpine**  
3.5 jack pins 1, 2 and 3  
Loop pins 9 + 10





**29-004 JVC**  
Single wire pin 3, 3.5 jack  
pins 2 and 3  
Loop pins 11 + 12




**29-007 Pioneer**  
3.5 jack pins 1, 2 and 3  
Loop 5 + 6 (some leads also  
have 7+8 looped, both are the same)




**29-011 Zenec**  
Single wire pin 3  
Loops 5 + 6, 7 + 8  
and 9 + 10




**29-003 Clarion**  
3.5 jack pins 2 and 3  
Loops 5 + 6 and 11 + 12



**29-005 Kenwood**  
Single wire pin 3  
Loop pins 7 + 8



**29-008 Sony**  
3.5 jack pins 1, 2 and 3  
Loops 7 +8 and 9 + 10



**29-012 Philips**  
Single wire pin 3  
Loops 5 + 6, 9 + 10  
and 11 + 12

## Troubleshooting

### Radio not turning on

Check there is an ignition power supply to the new head unit and the interface.

### Steering controls not working


Check the patch lead is correct and was connected to the interface before the interface was connected to the vehicle.

Reset the interface by completely disconnecting, wait for 2 minutes, then reconnect.


Check the wires in the harness are matching wires in the car.

Check the interface has software version SUZ01 V2.36 or newer.


## Patch lead wiring configurations




**29-000 Self learning units**  
Single wires pins 1 and 2  
No loops




**29-001 Alpine**  
3.5 jack pins 1, 2 and 3  
Loop pins 9 + 10





**29-004 JVC**  
Single wire pin 3, 3.5 jack  
pins 2 and 3  
Loop pins 11 + 12



**29-007 Pioneer**  
3.5 jack pins 1, 2 and 3  
Loop 5 + 6 (some leads also  
have 7+8 looped, both are the same)




**29-011 Zenec**  
Single wire pin 3  
Loops 5 + 6, 7 + 8  
and 9 + 10




**29-003 Clarion**  
3.5 jack pins 2 and 3  
Loops 5 + 6 and 11 + 12



**29-005 Kenwood**  
Single wire pin 3  
Loop pins 7 + 8



**29-008 Sony**  
3.5 jack pins 1, 2 and 3  
Loops 7 +8 and 9 + 10



**29-012 Philips**  
Single wire pin 3  
Loops 5 + 6, 9 + 10  
and 11 + 12

## Troubleshooting

### Radio not turning on

Check there is an ignition power supply to the new head unit and the interface.

### Steering controls not working

Check the patch lead is correct and was connected to the interface before the interface was connected to the vehicle.

Reset the interface by completely disconnecting, wait for 2 minutes, then reconnect.

Check the wires in the harness are matching wires in the car.

Check the interface has software version SUZ01 V2.36 or newer.