

Notes on connecting with 20-290-2CHP (2 Channel RCA ground loop isolator) to reduce external noise. THIS PART IS SOLD SEPERATLEY

Connect the RCA inputs on the 23-245 interface to the 20-290-2CHP and then connect that to the front right and left RCA outputs on the back of the aftermarket head unit.

The adjustment screws on the 20-290-2CHP can be adjusted up by turning them clockwise, or down by adjusting them anti-clockwise.

Set the head unit to a normal volume (where you can still have a conversation without shouting) and then bring the two adjustment screws on the 20-290-2CHP to zero so that no volume from the radio can be heard.

With the engine running, slowly adjust up the two screws until you have a satisfactory volume level or begin to hear any interference. Should interference be heard, bring the screws back down again slightly.

The 20-290-2CHP is sold separately.

To RCA inputs on 23-245
fibre optic interface.



To Front Right and Left
RCA outputs on
aftermarket head unit.

