

### **Installation Instructions**

White Left audio + White/black Left audio -Right audio + Grey Grey/black Right audio -

Yellow +12V input Black Ground

Blue +12V output signal

The adapter does not need to be powered to work, it only needs to be powered when using the remote output.



### **Installation Instructions**

White Left audio + White/black Left audio -Right audio + Grey Grey/black Right audio -

Yellow +12V input Black Ground

Blue +12V output signal

The adapter does not need to be powered to work, it only needs to be powered when using the remote output.

## 23-001 - 2 CHANNEL LINE OUT CONVERTER INCATTEC



### **Installation Instructions**

White Left audio + White/black Left audio -Right audio + Grey Grey/black Right audio -

Yellow +12V input Black Ground

Blue +12V output signal

The adapter does not need to be powered to work, it only needs to be powered when using the remote output.

# 23-001 - 2 CHANNEL LINE OUT CONVERTER INCATTEC



#### Installation Instructions

White Left audio + White/black Left audio -Grey Right audio + Grey/black Right audio -

Yellow +12V input Black Ground

Blue +12V output signal

The adapter does not need to be powered to work, it only needs to be powered when using the remote output.