50-369 Fitting Instructions



Remove the original radio using Philips/ Grundig radio release keys



Remove the metal bracket. This is tighten by Torx T20 screws.





Remove the top storage bin using a plastic wedge tool



Remove the plastic dashboard part which connects the frame from left to right.



Place the top storage bin and then the 2-Din replacement panel.



Place the 2-Din headunit. Place the radio trim.







Alpine IVA-W205R

We advice to use the following positions. Other positions are also possible.

Use position 2 marked with a cross. Use position 10 & 12 marked with an arrow. Measured from left to right.





Alpine IVA-W200Ri

We advice to use the following positions. Other positions are also possible.

Use position 2 marked with a cross. Use position 14 & 16 marked with an arrow Measured from left to right.

clarion







80

Clarion MAX668RVD

We advice to use the following positions. Other positions are also possible.

Use position 2 marked with a cross. Use position 12 & 14 marked with an arrow. Measured from left to right.

Clarion WXZ468RMP

We advice to use the following positions. Other positions are also possible.

Use position 2 marked with a cross. Use position 14 & 16 marked with an arrow Measured from left to right.

KENWOOD Listen to the Future





Kenwood DDX6029

We advice to use the following positions. Other positions are also possible.

Use position 1 marked with a cross. Use position 5 & 7 marked with an arrow. Measured from left to right.





Kenwood DDX 7025

We advice to use the following positions. Other positions are also possible.

Use position 1 marked with a cross. Use position 14 & 16 marked with an arrow Measured from left to right.







Pioneer HD1BT

We advice to use the following positions. Other positions are also possible.

Use position 1 marked with a cross. Use position 14 & 16 marked with an arrow. Measured from left to right.





Pioneer Avic D3

We advice to use the following positions. Other positions are also possible.

Use position 1 marked with a cross. Use position 9 & 11 marked with an arrow Measured from left to right.