


29-UCCAB patch lead wiring information




This is the wire entry side of the 4 way connector from the CAN interface box. The patch leads below will plug into this connector

When the UNICAN interface is connected to the car harness it will RECOGNIZE the car by a few red flashes and then as a single Green flash . **YOU NEED TO SET THE NUMBER OF FLASHES FOR THE BRAND OF HEAD-UNIT YOU ARE FITTING** . Using the cars steering wheel buttons press the VOL+ up to increase the flashes and VOL- to decrease the flashes. When you have the correct number of flashes use SEEK+ and the green light will stop flashing.

If you make a mistake, disconnect the interface , hold down the button, reconnect the interface then release the button and repeat the process above.


Number of flashes	Make of head unit
1	Clarion 3.5mm(Default)
2	Kenwood wire
3	JVC wire
4	Alpine 3.5mm
6	Pioneer 3.5mm (move jumper 1) Chinese 2 wire
7	Sony

These are the wire entry side of the Patch leads which will plug into the 4 way connector on the interface harness




29-UCCAB-001 Alpine

BLACK Base to black
WHITE Ring to brown * 13.7K resistor inline
RED Tip to purple




29-UCCAB-003 Clarion

BLACK to Base black
RED Tip to brown



29-UCCAB-007 Pioneer / Sony


RED Tip to purple
WHITE Ring to brown
BLACK Base to black



29-UCCAB-005 Kenwood or JVC


BROWN wire to brown

Connect the Brown wire to the Blue/Yellow single wire on the Kenwood or JVC marked STEERING WHEEL REMOTE INPUT



29-UCCAB-000 Chinese 2 wire Learning

PURPLE to Purple
BLACK to Black
Connect to the learning input wires on the head unit KEY1 and KEY Ground or SWC1 and SWC Ground



Connect the jack plug on these patch leads to the SWC input jack on the Aftermarket head-unit